




Acer Aspire 5334-2581 Battery Replacement

If your laptop does not hold charge, and you are sure that your power plug is working. This step by step guide will help you replace and reinstall your battery.


Written By: gilson teixeira



INTRODUCTION

Battery replacement is the easiest to replace, it should only take you about 5 minutes. Before starting your replacement, be sure to have unplugged the power cord.

Step 1 — Battery




- Please make sure your device is unplugged . Turn it over slowly, and place it on a flat surface.

Step 2




- This latch holds your battery in place, it should always be locked. Make sure to unlock this piece.
- ⚠ Do not break this latch, otherwise your battery will not hold in place.

Step 3



- Locate the eject latch and push it so the battery can come out.
- The battery will lift up once you have pushed the latch.
- ☑ You DO NOT need to adjust the latch when replacing the new battery, because it just snaps in place.

Step 4



- Lift the battery up, and it should just come right off. You should see the label with the part number.

To reassemble your device, follow these instructions in reverse order.